



PRESSURE LATERAL CONNECTION TO FORCEMAIN

NOT TO SCALE

NOTES:

1. PRESSURE LATERAL MUST BE A MINIMUM OF 4.5' DEEP.
2. SEE STANDARD DETAIL SHEET NO.12 OF 28 FOR BEDDING REQUIREMENTS.
3. BACKFLOW PREVENTER MUST BE CONSTRUCTED WITH A TRUE UNION SWING CHECK VALVE EQUAL TO THOSE MANUFACTURED BY SPEARS MANUFACTURING.

PRESSURE LATERAL CONNECTION

**SPRING - BENNER - WALKER
JOINT AUTHORITY**

DATE 11/2010
SCALE NTS
PROJECT
SHEET 25